


CUSTOM RISO SCREENS


*RISO'S ARE A SIMPLE, COST EFFECTIVE WAY TO SCREEN PRINT.
WE MAKE YOUR REUSABLE SCREEN FROM YOUR ART
YOU PRINT AT HOME.*

THERE ARE 2 SIZE OPTIONS:

HALF SCREEN



FULL SCREEN



ORDER ONLINE

- *UPLOAD YOUR ARTWORK AND PLACE YOUR ORDER FOR DELIVERY OR PICKUP*
- *WE PREPARE YOUR SCREEN IN 1-2 BUSINESS DAYS*
- *SCREENS ARE MADE OFF SITE AND CAN NOT BE MADE IN STORE WILE YOU WAIT*

THE BUTCHER SHOP

WWW.THEBUTCHERSHOP.AU

CUSTOM RISO SCREENS

RISO'S ARE A SIMPLE, COST EFFECTIVE WAY TO SCREEN PRINT.
WE MAKE YOUR REUSABLE SCREEN FROM YOUR ART
YOU PRINT AT HOME

ARTWORK GUIDELINES

SIZE

- YOUR DOCUMENT SHOULD BE THE SIZE OF THE DESIGN AREA
 - HALF SCREEN: 21 X 15 CM (OR IF A5 YOUR DESIGN WILL NOT BE RESIZED)
 - FULL SCREEN: 21 X 30 CM (OR IF A4 YOUR DESIGN WILL NOT BE RESIZED)
- SIT YOUR IMAGE IN THE DOCUMENT THE SIZE AND PLACE YOU WANT IT TO BE
 - IF ARTWORK IS NOT TO SIZE WE WILL BY DEFAULT MAKE IT THE MAXIMUM SIZE POSSIBLE ON THE SCREEN
- IMAGES SHOULD BE OF PRINT QUALITY, MIN 300 DPI
 - IF YOU PRINT YOUR DESIGN ON YOUR HOME PRINTER AND IT IS FUZZY OR PIXELATED YOUR SCREEN WILL BE ALSO

FILE TYPES

- JPG, TIF, PNG OR PDF

DESIGN

- CLEAR BLACK AND WHITE IMAGES WORK BEST, PREFERABLY WITH NO GREY SCALE
 - IF YOUR ARTWORK HAS GREY AREAS LIGHTER SHADES MAY DISAPPEAR FROM YOUR SCREEN
 - ARTWORK MUST BE BLACK AND WHITE (NOT COLOUR)
- ALL BLACK AREAS ON YOUR DESIGN WILL BE THE 'HOLES' IN YOUR SCREEN THAT WILL LET YOUR CHOICE OF COLOURED INK THROUGH DURING PRINTING
- ALL WHITE AREAS ON YOUR DESIGN WILL BLOCK THE INK FROM COMING THROUGH THE SCREEN

EXAMPLE OF GREY SCALE ARTWORK DETAIL LOSS

- TO HAVE MORE CONTROL OF HOW YOUR ARTWORK WILL APPEAR ONLY SUBMIT ARTWORK WITH BLACK
- IF YOUR ARTWORK HAS GREY WE WILL CHOOSE THE CONTRAST LEVEL AT OUR DISCRETION



ORIGINAL ARTWORK



SCREEN RESULT

WHAT ARE THE SCREENS LIKE?

THE SCREENS ARE A THIN, DURABLE PLASTIC MESH. YOUR DESIGN IS PERMANENTLY IMPRINTED WITH THERMAL TECHNOLOGY ON TO THE SCREEN. YOU CAN WASH AND REUSE YOUR SCREEN MANY TIMES. SCREEN FRAMES CAN BE PURCHASED SEPARATELY IF YOU WISH TO STRETCH YOUR MESH ON TO A FRAME, THEY CAN ALSO BE USED DIRECTLY ON TO YOUR PRINT SURFACE WITH NO FRAME.

WHAT CAN I PRINT ON?

RISO SCREENS ARE PERFECT FOR PRINTING ON TO TEE SHIRTS, TOTE BAGS, PAPER AND MUCH MORE.

WHAT CAN I PRINT WITH?

SCREENS ARE IDEAL TO USE WITH OUR SCREEN PRINTING INK, BUT CAN BE USED WITH A WIDE VARIETY OF PAINTS AND INKS. IF THE PAINT/INK YOU WANT TO USE IS NOT WATER BASED, PLEASE TEST YOUR CLEAN UP SOLVENT WITH THE MESH AS IT MAY ATTACK THE SCREEN.

CAN MY PRINT BE MULTIPLE COLOURS?

ONE COLOUR PRINTS ARE ALWAYS EASIER, BUT MULTI COLOURED PRINTS ARE POSSIBLE. MULTIPLE COLOURED PRINTS ARE MADE WITH ONE COLOUR PER SCREEN, LAYERING A NUMBER OF PRINTS ON TOP OF EACH OTHER. YOU MAY NEED EXTRA EQUIPMENT FOR ACCURATELY ALIGNING YOUR PRINTS (SUCH AS A PRINTING JIG). YOU CAN ALSO CREATIVELY GET MULTIPLE COLOURS ON TO PRINTS IN OTHER WAYS - CHECK OUT SOME INSPIRATION AT WWW.THEBUTCHERSHOPAU/RISO

WHICH IS THE RIGHT SIDE?

IF YOU CAN'T TELL BY LOOKING AT YOUR DESIGN, FEEL BOTH SIDES OF THE MESH - THE SMOOTH SIDE IS ALWAYS TOUCHING THE PRINTING SURFACE (IE TEE SHIRT) AND THE ROUGH SIDE IS THE SIDE YOU WILL PUT YOUR INK ON.

IF ATTACHING YOUR SCREEN TO A RISO FRAME ATTACH THE SHINY SIDE TO THE FRAME. YOUR MESH WILL SIT ON TOP OF THE FRAME AND YOUR PRINTING SURFACE (IE TEE SHIRT) WILL TOUCH THE BOTTOM OF THE FRAME LEAVING A SMALL GAP BETWEEN THE PRINT SURFACE AND MESH.

CARING FOR YOUR SCREEN

- REMOVE EXCESS INK BEFORE PLACING UNDER RUNNING WATER (OR USING CLEANERS) TO DISSOLVE INK
- WIPE ON TOP (ROUGH SIDE) OF MESH WITH A SOFT CLOTH
- DO NOT WIPE/RUB FILM/SMOOTH SIDE
- DO NOT USE HOT WATER OR HIGH PRESSURE WHEN CLEANING
- IF USING SOLVENTS TEST ON SCREEN MATERIAL FIRST

SCREENS WILL LAST MANY YEARS IN STORAGE WHERE SUITABLE CONDITIONS ARE PROVIDED

- STORE AWAY FROM HUMIDITY, IN A COOL PLACE OUT OF DIRECT SUNLIGHT
- MESH CAN BE STORED STRETCHED ON A FRAME OR STORED ROLLED WITH SMOOTH SIDE OUTWARDS

THE BUTCHER SHOP

WWW.THEBUTCHERSHOP.AU

HALF SCREEN



OPTIONAL FRAME

*YOUR ARTWORK FILE
DIMENSIONS SHOULD MATCH
DESIGN AREA*


*PLACE YOUR IMAGE IN YOUR
ARTWORK FILE THE SIZE YOU
WANT IT - IT CAN GO RIGHT TO
THE EDGES. THERE WILL BE
EXTRA MESH AROUND THE
DESIGN AREA.*

FULL SCREEN



OPTIONAL FRAME

YOUR FILE SIZE



IF YOUR FILE SIZE IS:


HALF: 21 X 15CM OR A5 DIMENSIONS

FULL: 21 X 30CM OR A4 DIMENSIONS


YOUR FILE WILL BE PLACED 'AS IS' AND ANY WHITE SPACE AROUND YOUR IMAGE WILL REMAIN AS PER YOUR DESIGN

YOUR FILE EDGE

YOUR IMAGE PLACEMENT WITHIN YOUR FILE



IF YOUR FILE SIZE IS NOT THE DIMENSIONS OF THE ARTWORK AREA IT WILL BE RESIZED SO THE IMAGE AREA APPEARS AS LARGE AS POSSIBLE ON YOUR SCREEN AND PLACED IN THE CENTRE.



YOUR FILE